



KEITH PRODUCTS, L.P.
ENVIRONMENTAL SYSTEMS

CERTIFICATION REPORT NO. CR-1124-9
AIR CONDITIONING/HEATING SYSTEM INSTALLATION
FLIGHT MANUAL SUPPLEMENT
FOR
WESTWIND MODELS:
1124/1124A

STC NO. SA5556SW

Date: October 14, 1983
Rev: NC
Rev. Date: _____

Keith Products L.P..
4554 Claire Chennault
Dallas, Texas 75248

FAA APPROVED SUPPLEMENT
TO
FAA APPROVED AIRPLANE FLIGHT MANUAL
FOR
WESTWIND MODELS 1124 - 1124A

MODEL _____
REG. NO. _____
SER. NO. _____

This Supplement must be attached to the applicable FAA Approved Airplane Flight Manual when a Keith Products Freon Air Conditioner is installed per STC No. SA5556SW. The information contained herein supplements the information of the basic AFM; for Limitations, Procedures and Performance information not contained in this Supplement, consult the basic AFM.

SECTION I. CERTIFICATE LIMITATIONS

1. Air Conditioning NOT to be used above 18,000 feet.
2. Air Conditioning must be turned OFF with loss of a generator and/ or engine.
3. Do NOT operate air conditioner when windshield heat is on.

PLACARD, located above air conditioning control switches.

FL 180 MAX OPER

DO NOT OPER WITH


WINDSHIELD HEAT ON

SECTION II. EMERGENCY PROCEDURES
No Change.

SECTION III. ABNORMAL PROCEDURES
No Change.

SECTION IV. NORMAL PROCEDURES
Amber light located next to switch indicates
Air Conditioner is operating.

SECTION V. PERFORMANCE DATA
No Change.

FAA APPROVED: 
Don P. Watson
Aircraft Certification Division
Southwest Region, FAA
Fort Worth, Texas 76101

DATE: OCT 14 1983

REVISED: _____

Keith Products L.P..
4554 Claire Chennault
Dallas, Texas 75248

FAA APPROVED SUPPLEMENT
TO
FAA APPROVED AIRPLANE FLIGHT MANUAL
FOR
WESTWIND MODELS 1124 - 1124A

MODEL _____
REG. NO. _____
SER. NO. _____

This Supplement must be attached to the applicable FAA Approved Airplane Flight Manual when a Keith Products Freon Air Conditioner is installed per STC No. SA5556SW. The information contained herein supplements the information of the basic AFM; for Limitations, Procedures and Performance information not contained in this Supplement, consult the basic AFM.

SECTION I. CERTIFICATE LIMITATIONS

1. Air Conditioning NOT to be used above 18,000 feet.
2. Air Conditioning must be turned OFF with loss of a generator and/ or engine.
3. Do NOT operate air conditioner when windshield heat is on.

PLACARD, located above air conditioning control switches.

FL 180 MAX OPER

DO NOT OPER WITH

WINDSHIELD HEAT ON

SECTION II. EMERGENCY PROCEDURES
No Change.


SECTION III. ABNORMAL PROCEDURES
No Change.

SECTION IV. NORMAL PROCEDURES
Amber light located next to switch indicates Air Conditioner is operating.

SECTION V. PERFORMANCE DATA
No Change.

FAA APPROVED: 

Don P. Watson

 Aircraft Certification Division
Southwest Region, FAA
Fort Worth, Texas 76101

DATE: OCT 14 1983

REVISED: _____